

珠海市魅族科技有限公司

MEIZU TECHNOLOGY CO., LTD.

广东省珠海市科技创新海岸魅族科技楼

MEIZU Tech Bldg., Technology & Innovation Coast,
Zhuhai 519085, Guangdong, China

Tel /86-756-6116288

Fax/86-756-6116200

M1712 after-sale maintenance manual

(Version: V1.0)

Edit by : Huang Shifeng

Review by : Zhong Zhifeng

Approve by : Wang Chuansan

Issue date : Dec, 21th 2017

Implementation data : Dec, 21th 2017

Catalog

M1712 maintenance manual	1
Chapter 1 Caution of Maintenance	3
Chapter 2 M1712 product introduction	4
2.1 Product appearance	4
2.2 Hardware specification	7
2.3 Maintenance of matters needing attention	9
Chapter 3 Position diagram of components	9
Chapter 4 Function and test mode	11
Chapter 5 Maintenance tools	11
Chapter 6 Common fault detection and maintenance	13
6.1 No boot issue	13
6.2 Chagre Malfunction	13
6.3 LCD Malfunction	15
6.4 Button Malfunction	16
6.5 Ringtones Malfunction	17
6.6 Receiver Malfunction	17
6.7 SIM card Malfunction	18
6.8 Camera Malfunction	19
6.9 Headset Malfunction	19
6.10 WIFI/BT/FM/GPS Malfunction	20
6.11 Network Malfunction	22
6.12 Touch screen Malfunction	24
6.13 Sensor Malfunction	25
6.14 Mic Malfunction	27
6.15 Flash light Malfunction	28

Chapter 1 Caution of Maintenance

Caution:

1. Only authorized technicians can do maintenance and calibration.
2. Make sure that engineers wear antistatic wrist strap repair phones in antistatic station.
3. Make sure that maintenance room is covered with antistatic mat, and the maintenance table is covered with antistatic material.
4. Make sure that all necessary screws and parts are installed in correct location of phone after maintenance and adjustment.
5. After maintenance, clean the PCBA.
6. As static electricity is the main reason for electronics damages, engineers shall repair phones in an anti-static environment and shall take effective antistatic protection measures.
7. For an occurrence of NG test, engineers should check if the test point is dirty or test point contact is poor.
8. Check if water penetrates to mainboard. If yes, check all the components to see if there is oxidation.
9. Make sure that maintenance room is bright and has natural ventilation.
10. Ventilation: When do maintenance or soldering, some equipment can emit hazardous gas. So the maintenance room should have good natural ventilation. If there are no windows in maintenance room, the room should be equipped with electric air regenerating equipment.
11. There should be obvious antistatic labels in Electrostatic Sensitive area, such as in maintenance area and spare part warehouse.

Chapter 2 M1721 product introduction

珠海市魅族科技有限公司

MEIZU TECHNOLOGY CO., LTD.

广东省珠海市科技创新海岸魅族科技楼

MEIZU Tech Bldg., Technology & Innovation Coast,
Zhuhai 519085, Guangdong, China

Tel /86-756-6116288
Fax/86-756-6116200

2.1 M1712 Brief Introduction

M1712 View :

TRAY

C: Black

M: Lead

F: Sand blasting oxidation CNC

VOL KEY

C: Black

M: Lead (same color highlight)

F: Sand blasting, oxidation ,Diamond Cutting
bright side C corner

前壳

C: Black

M: PA+55%GF

F: Highlight



珠海市魅族科技有限公司
MEIZU TECHNOLOGY CO., LTD.

广东省珠海市科技创新海岸魅族科技楼
MEIZU Tech Bldg., Technology & Innovation Coast,
Zhuhai 519085, Guangdong, China

Tel /86-756-6116288
Fax/86-756-6116200

Receiver

C: half matt gloss

M: Stainless steel

F: PVD

Backlight silk print R printing ink

背光源印R油墨

听筒网

C: 半光黑色

M: 不锈钢

F: PVD

Front camera

前置摄像头



TP

C:Black


M:2.5 glass

F: silk print of back

珠海市魅族科技有限公司
MEIZU TECHNOLOGY CO., LTD.

广东省珠海市科技创新海岸魅族科技楼
MEIZU Tech Bldg., Technology & Innovation Coast,
Zhuhai 519085, Guangdong, China

Tel /86-756-6116288
Fax/86-756-6116200



珠海市魅族科技有限公司
MEIZU TECHNOLOGY CO., LTD.

广东省珠海市科技创新海岸魅族科技楼
MEIZU Tech Bldg., Technology & Innovation Coast,
Zhuhai 519085, Guangdong, China

Tel /86-756-6116288
Fax/86-756-6116200



珠海市魅族科技有限公司
MEIZU TECHNOLOGY CO., LTD.

广东省珠海市科技创新海岸魅族科技楼
MEIZU Tech Bldg., Technology & Innovation Coast,
Zhuhai 519085, Guangdong, China

Tel /86-756-6116288
Fax/86-756-6116200


2.2 Hardware specification

Hardware	Hardware configuration classification	Describe
Platform	Platform of base band' s chipset	Exynos 7872
	GPU	Mali-G71 MP1
	RF receive and send	RF S925
	Power supply chipset	S2MPU07
	GPS/WIFI/BT/FM chipset	S611
	Technical standard	LTE (Full Netcom 6 mode 19 frequency band)
(Full Netcom) frequency band	LTE TDD frequency band	TDD-LTE : B34/B38/B39/B40/B41
	LTE FDD frequency band	FDD-LTE : B1/B3/B8
	WCDMA frequency band	WCDMA : B1/B2/B5/B8
	TD-SCDMA frequency band	TD-SCDMA : B34/B39
	GSM frequency band	GSM : B2/B3/B5/B8
Peripheral equipment	GPS	GPS/Glonass
	WIFI	Support 2.4G/5G WIFI ; 802.11a/b/g/n
	NFC	No
	Bluetooth	Support BT4.2
	FM	No
	ATV	No
	HD Voice	No
	HALL	No

2.3 Maintenance of matters needing attention

- 1) It need to repeat the MMI test in maintain after we disassemble to fix the issue. If you needn' t disassemble. And you still can fix the issue. You can delete the customer data.
- 2) If you need to replace the mainboard .You should confirm that the Flyme firmware is the latest version.

Chapter 3 Position diagram of components



Main board(A)

珠海市魅族科技有限公司


MEIZU TECHNOLOGY CO., LTD.

广东省珠海市科技创新海岸魅族科技楼

MEIZU Tech Bldg., Technology & Innovation Coast,
Zhuhai 519085, Guangdong, China

Tel /86-756-6116288

Fax/86-756-6116200



Chapter 4 Function and test mode

MMI test command *983*1#

Check version command *983*7#

(Note: Just for engineer firmware version)

Chapter 5 maintenance tools

珠海市魅族科技有限公司
MEIZU TECHNOLOGY CO., LTD.

广东省珠海市科技创新海岸魅族科技楼
MEIZU Tech Bldg., Technology & Innovation Coast,
Zhuhai 519085, Guangdong, China

Tel /86-756-6116288
Fax/86-756-6116200



CMU200 Or 8960



DC Power supply



Oscilloscope



Hot air gun



Electric iron



Spectrum analyzer



Antistatic gloves



Lead-free solder wire



Antistatic cloth



Alcohol bottle



Brush



Antistatic brush



Antistatic-fixtue


Chapter 6 Common fault detection and maintenance

6.1 No boot issue

Peripherals problem:

1 Make sure that battery functions properly, and that the voltage of battery is more than 3.45V enough to power on the phone.

2 Make sure that the Power button functions properly, and that the signal voltage of PWRKEY changes from low to high potential when phone is powered on.



PCB problem

After peripherals problems is troubleshot, connect the phone with DC power supply and switch on phone to check electric current.

1. If the starting current is supper after the phone is connected with DC power supply, the phone has shortcut problem. Super-current shortcut generally emits heat so that you can use hands or thermal imager to view heat point.

2. When the starting current is around 100MA, you probably did not download the right software. Therefore you can try to re-download the software.

6.2 Chagre Malfunction


Peripherals problem::


1. Make sure that battery functions properly, and that voltage of battery is not less than 2.8V.

2. Make sure that the USB data cable and adapter function properly.

3. Make sure that the USB-FPC functions properly and is well connected with mainboard.
PCB problem:

Check to ensure charge components (Mainly are CON2203, U2206) have no defects.





6.4 Button Malfunction


6.4.1 Check to ensure that gold finger of FPC button is connected with VSYS signal, and that PWRKEY are respectively connected with TP2205. If disconnection occurs, the reason is that CON2204 is disconnected or the FPC is damaged.


6.4.2 Check to ensure VOLUMEKEY of FPC button is connected with mainboard GND. VOL_UP_CON、VOL_DOWN_CON are respectively connected with TP2207, TP2206. If disconnection occurs. The reason is that the FPC is damaged.

6.4.3 Make sure that FPC is well connected with mainboard. The Voltage of gold finger changes from low to high potential at normal use. If no changes occur, it means that the CPU (U1801) is damaged.

6.4.4 Make sure that FPC is well connected with mainboard. The Voltage of POWERKEY FPC change from low to high potential at normal use. Is no changes occur, it means that the (U1801) is damaged.

6.4.5 Make sure that FPC is well connected with mainboard. The Voltage of VOLUMEKEY FPC change from high to low potential at normal use. Is no changes occur, it means that the (U1501) is damaged.






6.5 Ringtone Malfunction

6.5.1 Measure to ensure R1003 and R1008 are well connected with positive and negative electrodes of speaker. If disconnection happens, check if FPC has defects or connectors CON1001, CON2203 are disconnected.


6.5.2 Play music to ensure SPK_P and SPK_N have signal. If there is no signal, check if any components or U2501, U1801 were damaged.



6.6 Receiver Malfunction

6.6.1 Confirm receiver was well connected with pad.


6.6.2 Measure to check if REC+, REC- have signals in mode of earphone. If there is no signal, check if any components or U1801 was damaged.




6.7 SIM card Malfunction

6.7.1 Check to sure CON2003 and CON2002 were no damaged. Make sure the SIM card is normal.

6.7.2 Measure to ensure that the voltage of VSIM_PMU is normal; Measure to ensure there are signal in SIM_CARD_SRST, SIM_CARD_SCLK and SIM_CARD_SIO. For an occurrence of inconformity, it's an issue of U1501.







6.8 Camera Malfunction

6.8.1 Check to ensure that cameras is normal, and that camera is well connected with CON1901 and CON1902.

6.8.2 Check to ensure circuit components has no defects.

6.8.3 Measure to ensure the voltage of VCAMD_PMU、VCAMA_PMU、VCAMD_IO_PMU is normal, If it' s unnormal, U1801, U1913 or U1917 have defect.





6.9 Headset Malfunction

6.9.1 Check to ensure that earphone has no defects, and that earphone is well connect with CON1002


6.9.2 Check to ensure PCBA circuit and components have no defects.

6.9.3 Measure to ensure that the signal level of ACCDET is not lowered in mode of earphone, and that AU_HPR, AU_HPL can output signal. If abnormality occurs, it's an issue of PMU (U1801).




6.10 WIFI/BT/GPS Malfunction


6.10.1 Check to ensure that antenna is well connected.



6.11 Network Malfunction

- 6.11.1 Check to ensure that antenna is well connected, and that antenna has no visual defects.
- 6.11.2 Check to ensure the PCBA circuit and components have no defects.





6.13 Sensor Malfunction

6.13.1 Check to ensure that PCBA circuit and components have no damages (U2301、U2303、U2304) , and that light-sensitive sensors (U2301) are not covered by obstacles.


6.13.2 Measure to ensure the voltage of AVDD28_PMU and all the sensors are with specification. If the voltage is beyond the standard, check if CPU (U1501) has defects.

珠海市魅族科技有限公司
MEIZU TECHNOLOGY CO., LTD.

广东省珠海市科技创新海岸魅族科技楼
MEIZU Tech Bldg., Technology & Innovation Coast,
Zhuhai 519085, Guangdong, China


Tel /86-756-6116288
Fax/86-756-6116200

M-Sensor



Accerometer + Gyro Sensor

LSM6DS33 (A+Gyro) I2C Address: 0x6AH (Write: 0xD4H, Read: 0xD5H) - 已查




珠海市魅族科技有限公司
MEIZU TECHNOLOGY CO., LTD.

广东省珠海市科技创新海岸魅族科技楼
MEIZU Tech Bldg., Technology & Innovation Coast,
Zhuhai 519085, Guangdong, China

Tel /86-756-6116288
Fax/86-756-6116200

Ambient Light Sensor with Proximity Sensor



6.14 Mic Malfunction

6.14.1 Respectively measure contact point MIC_P_BT B and MIC_N_BT B to ensure the two contact points are well connected with MIC electrodes. If disconnection occurs, check if the FPC is damaged or connectors (CON2203) are disconnected.

6.14.2 Check to ensure PCBA circuit and components have no damages. If there are no defects, check PMU (U1801).

Flash LED 5V Boost

